



specifications

Total Length 🌒 310mm
Effective Length (Tonearm pivot to cartridge stylus)
Practical Length (Tonearm pivot to spindle)
Overhang 16mm
Offset angle 22.25°
Horizontal moving sensitivity 30mg
Vertical moving sensitivity 20mg
Vertical Tracking Force (VTF) range 0-4.5g (3+1.5g)
Cartridge plus Headshell weight range 15-45g
Antiskating Adjustment 0-3g (Equivalent to Stylus VTF)
Vertical Bearing Miniature Radial Bearing
Horizontal Bearing Miniature Radial Bearing
Height Adjustment (Plinth to arm-wand centerline) • 15-55mm
Output plug RCA (XLR as an Option)
Output cable Single core shielded copper
Tonearm Audio Lead wire 🌒 High Purity Silver (Internal Wiring)
Headshell lead wire Silver with gold plated terminal
Headshell Machine tooled Aluminum
Tonearm Net Weight 755g
Attached standard Headshell Net Weight 🌒 17g







Mount the tonearm base to turntable plinth / Arm Boad

1-a Determine where the arm base should be mounted by using the supplied arm mounting template.

1-b Put the larger hole of the template onto the center spindle. Take the attached marking pin supplied (as illustrated below) and push it through the small hole at the opposite end of the tonearm template (the hole opposite the spindle hole). Keep the needle perpendicular to the template. You may now mark the center point of the tonearm base. The center point of the tonearm base is also the pivot point.

1-c At the same time, mark the 3 holes for the screws that mount the arm base to the armboard.

1-d Do not drill holes yet !

1-e Having marked the center, check to see if there is sufficient clearance for the tonearm and the dust cover (if you have a dust cover). Pay particular attention to the counterweight shaft.

1-f After you have verified the dust cover will work with the chosen arm base location, drill one 22mm hole (this is the center, which allows access to the tonearm stem and cable) and three 3.5mm holes (for the screws that mount the arm base).

* 22mm diameter hole: For tonearm shaft!

* 3 x 3.5mm diameter holes: For tonearm base fixing screws!

Attach the cartridge to headshell

Connect the wire leads to the cartridge pins, and attach the cartridge to the headshell with screws. (See the figure below) Screws are not included in this tonearm kit. They are usually included with the cartridge, from the cartridge manufacturer.in mm, will give accurate results.

Headshell Azimuth Adjustment

6-a Sorane tonearms come with adjustable headshells. There is an Allen or hex set-screw in the side of the headshell. There is a corresponding Allen/Hex Key to allow the user to adjust the headshell.

6-b As shipped from the factory, the headshell adjustment Allen set-screw is set to approximately 90 degrees, with the intention that customers should adjust the headshell to match their unique setup (cartridge, plinth, platter, etc.). Customers are requested to make final adjustments after mounting the cartridge, then installing the headshell on your Sorane tonearm. It is important to make sure the stylus is perpendicular to the surface of the record. Often it is helpful to use a mirror (if you do not have a mirror, a CD will also work). The main thing is to understand that many stylus assemblies are not perfectly perpendicular, and sometimes platters are concave, so that it is important to adjust the stylus until it is perpendicular with the groove.



3 個色 2 1

If the tracking force needed is 3 grams, set the middle sliding counterweight at the mark for 3 grams on the weight gauge. If more than 3 grams of tracking force is needed, use the auxiliary weight of 1.5 grams, along with the counterweight, in order to secure your desired tracking force. For instance, the ancillary weight of 1.5 grams, plus 2.5 grams of tracking force set by the middle sliding counterweight, is equivalent to 4 grams total tracking weight.

Example

Mount SA-1.2BCS shaft through the Base hole

2-a Carefully push the tonearm shaft through the hole in the arm base and then fasten the set-screw with the hex key supplied with the tonearm. Be careful not to over tighten!

2-b Adjust the tonearm height to make the tonearm parallel with the surface of the record when the stylus is touching the record. This is the starting point, and further fine tuning may be necessary depending on the geometry and the stylus type of the cartridge. Consult the cartridge manufacturer for correct VTA and VTE!

2-c The cueing platform has already been set at the correct height but can be adjusted by using the supplied hex key.

Cartridge tracking force adjustment

3-a Verify that the anti-skating knob (number 3) is set at 0 grams.

3-b Ensure that the sliding tracking force adjustment knob (number 4) is set to zero (the point furthest to the back of the tonearm and closest to the pivot point).

3-c After the cartridge is correctly adjusted for overhang, adjust the counterweight (number 1) so that the arm is floating with the stylus approximately 3-5mm clear of the vinyl record. Once this adjustment is made, the counterweight should be fixed by the set-screw located on the side of the counterweight (number 2 below), using the supplied hex key.

3-d Add tracking force by using the sliding counterweight located in the middle of tone arm (number 4 below). As the middle counterweight slides forward, the tracking force increases. The tracking force can be increased to a maximum of 3.0 grams with the middle sliding counterweight pushed all the way forward to the headshell end of the tonearm (each step is equivalent to 0.5 grams x 6 steps, making 3 grams).

3-e The auxiliary weight is 1.5 grams (see 5). If more than 3 grams of tracking force is needed, as might be the case when playing 78 rpm records, place the ancillary weight in the hole as illustrated in the drawing (see 5). Only use this auxiliary weight if additional tracking force is needed! If it is not needed, store it away in a safe place.

Note

Because the tracking force mechanism (see 4) of SA-1.2BCS is different from a standard counterweight system, the use of a separate VTF gauge for precise fine-tuning is recommended. The relative accuracy of the SA-1.2 tracking force mechanism is somewhat affected by the complex interaction of the mass of the main counterweight, its position, the mass of the cartridge, and the mass of the headshell. So, as is usual with all tonearms, you should verify the desired tracking force with a calibrated VTF gauge.

Auxiliary counterweight stem

In case the standard counterweight is not heavy enough to balance your cartridge/headshell combination, an additional counterweight stem has been supplied to give additional mass, and greater range of adjustment.

4-a Remove the counterweight and headshell, setting them





aside in a safe place.

4-b Inspect the threads on the auxiliary counterweight stem. If there is any debris, please brush it with a small paint brush, or clean toothbrush. Debris can cause the threads to become stuck.

4-c Attach the auxiliary stem by carefully threading clockwise into the main stem. The threads are normal "right-hand threaded".

4-d Tighten firmly with your fingers, but do not apply aggressive force. Do not use a wrench, or other tool that would apply too much force on the bearings. Do not use thread-locking compound (removal would require excessive force). Finger-tighten only!

4-e The auxiliary counterweight stem provides two methods of counter-balancing heavier cartridges and headshells.

1-The weight of the auxiliary stem provides additional force.

2-The stem also provides much greater range of adjustment of the main counterweight (the zero-set counterweight).



Anti-skating (bias) adjustment

Set the bias adjustment knob to the same number as the tracking force. Some experimentation may be necessary based on the specific stylus profile used by the cartridge.

Converting between "Positive" and "Negative" Counterweight stub

There are two counterweight stubs supplied with the the SA1.2BCS. Inscribed on the back of both stubs will be "P" or "N". P is for Positive, a reference to positive balance. "N" is for Negative, a reference to negative balance. The inscription faces the tonearm Arm Bearing Box, and is not seen during operation. Refer to the SA1.2BCS brochure to learn about the benefits of positive versus negative balance.

Abbreviations: Arm Bearing Box = ABB Cueing Device Base = CDB Arm Main Pillar = AMP Anti-Skating = AS





Negative

The two counterweight stems are etched with a "P" and "N" to differentiate the two. The difference in center-ofbalance is due to where the hole is machined that holds the counterweight shaft. The supplied stems are assembled (the image above shows the parts before final assembly).



A When you unpack the SA1.2BCS, you are suggested to confirm counterweight shaft is in Positive position. The horizontal shaft of the "Positive Balanced" stub will be lower, compared to the shaft of the main arm wand. The horizontal shaft of the "Negative Balanced" stub will be at the same horizontal plane as the main arm wand. In the picture below, notice that the shaft is lower than the horizontal plane of the main arm wand (this is the "Positive Balanced" stub);

B Prior to start operation to change the stub to "Negative Balance", make sure the arm is in the arm rest, the cueing device is in the "down" position, and turn over the tonearm on a soft surface to prevent scratches. You must retain this configuration after the installation of the new counterweight stub;

C Please note illustration, there is a very fine nylon string between Anti-Skating device and tonearm Main Pillar. It should never be cut, even by accident, during this tonearm stub changing operation;

D Unscrew the two hex keys head set-screws that secure the Cueing Device Base. Lower the CDB down the Arm Main Pillar. If the arm is brand new and never used, there will be nylon tubing around the AMP to protect its surface. You must lower or remove it before lowering the CDB;

E The left figure shows the CDB position after lowering down the AMP. This allows room to insert the Allen key for unscrewing the set-screws;

F Do not lower the CDB too much since you could break the nylon string or even damage the Anti Skate device;

G Insert Hex key into Allen head set-screws;

H After unscrewing 2 screws, carefully pull the stub from ABB.

I Prepare the other Negative Balance Stub.

Thank you for choosing Sorane! As IT Industry values the customer, and strives to offer the best performance, we are sure you will enjoy many hours of clear and dynamic sound. Happy listening!

